



P26RGT
USER MANUAL

Extreme output outdoor flashlight

The Fitorch P26RGT is a high performance flashlight with a superb output of 5000lms. It utilizes a High XHP70.3 LED, with an optimized optical system, which enables its beam distance to reach 320 meters. It is powered by 1*26650-5000mAh rechargeable battery, which extends the runtime to 270 hours. The compact design and the simple function operation interface to make it to be confidently meet all needs of outdoor activities, everyday-carry, searching, and hiking.

Specification

- 5000 lumens maximum output and 320 meters maximum beam distance.
- High performance High XHP70.3 LED.
- High-transmitting optical glass with AR coating.
- 26650-5000mAh rechargeable battery.
- Modes: Turbo-High-Medium-Low-Eco and Strobe & SOS.
- Lock&unlock function, and one key to Turbo
- Power indication and low-voltage warning function.
- Built-in location beacon function
- Anti-roll integrated housing
- IPX8 waterproof
- Dimensions: $\phi 37^*L133.4MM$
- Weight: 230g(without battery)
- Accessories Included: 1*charging cable, 1*26650 battery, 1* lanyard, 1* holster, 1* O-ring

P26RGT Data


Mode	Turbo	High	Medium	Low	ECO	Strobe	SOS
OUTPUT	5000 Lumens	2000 Lumens	780 Lumens	150 Lumens	7 Lumens	5000 Lumens	150 Lumens
RUNTIME	3.2h (100% 15000mAh)	3.5h	6.5h	25h	270h	—	—
INTENSITY	22569cd						
DISTANCE	320m						
WATERPROOF	IPX8						
IMPACT RESISTANCE	1m						

Note: all data above were generated in Fitorch lab. Differences may happen basing on usage and conditions.

Operation

- **On/Off:**
Click the side switch to turn on the light, and then press and hold the side switch for 0.5s to turn off the light.
- **Mode Change:**
When power on, click the side switch to cycle through Eco-Low-Medium-High-Eco-Low.
- **Turbo:**
When the light is unlock, double click the side switch to enter Turbo.
- **Strobe&SOS:**
Double click the side switch to activate Strobe, and then double click the side switch againto enter SOS.

- **Lock&Unlock:**
When power off, press and hold the side switch for 5 seconds until the LED flashes, and then the light is locked. Repeat the above steps to unlock the light.
- **Power Detection:**
When the light is off, click the side switch 4 times quickly to activate the power detection function. The indicator light on the switch will blink to indicate the voltage. Each green blink indicates 1.0V, and each red blink indicates 0.1V.
- **Beacon Locating Function:**
When power off, click the side switch 5 times to activate Beacon locating function, and click the switch again to enter ECO mode. Click the switch 5 times again to close the Beacon locating function.
- **Charging**
Switch off the light, and remove the USB cap to reveal the USB Type-C charging port, then connect the charging port with the power source via charging cable. The indicator below the side switch will be red during charging, and it will change to green after charging.



Usage and Maintenance

- Disassembling the sealed head will damage the lights and void the warranty.
- High quality batteries are recommended.
- O-ring will be wear after a Long-term use, change it In included spare one to maintain watertight seal.
- Unload the batteries if assure the light won't use a bit of long time, then better put It into Inner box(Built-in battery excluded).
- Store and keep the light off fire, statics, steaming and humidity surroundings.
- Clean the body with soft fabric clothing then lubricate In silicon grease per half a year.
- Periodic cleaning of batteries contacts to improve the flashlight performance as dirty contacts cause the lamp flicking, shine intermittently or even fail to illuminate for below factors(Built-in battery excluded).
A: Battery needs replacing (choose the battery which mentions on this manual)
B: PCB, Spring or other contacts is dirty (clean the contacts In cotton swab In soaked rubbing alcohol)

WARNING!

- Looking at the light for a long time will harm your eyes. Don't shine the light directly into anyone's eyes.
- The light will accumulate a lot of heat when used for extended periods, resulting in a high temperature of the light housing. Pay attention to safe use to avoid scalding.
- Do not shine the light to an object at close range to avoid burning the object or causing danger due to high temperature.

Warranty

- 15 days replacement: Fitorch will replace identical or equal products with documented manufacturing defects within 15 days of purchase.
- 5-year free repair: This light is non-detachable and enjoy the service of 5 year free repair of purchase if problems happen in normal use.
Rechargeable battery enjoys 1-year warranty.



Facebook



Website

ShenZhen Fitorch Electronics Technology Co., Ltd
Office Address: 2F, Building 2, 3rd Industrial Zone,
Longhua St, Longhua District, ShenZhen City, 518109,
China
Tel: +86-755-2101-3606
Web: www.fitorchworld.com
E-mail: Info@fitorchworld.com

